



Designers and Manufacturers of Mobile Health Clinics

ADI Technical Bulletin #15

ADI Mobile Clinic Power

IMPORTANT NOTES - PLEASE READ

ADI Mobile Clinics may be operated in varying power level modes:

- Battery only mode: general lighting, steps, propane furnace, vents, stereo, refrigerator(s), etc. (Good for 1-3 days).
- A plugged in, “low power”, limited functions mode using only the battery charging cord (120VAC, 15 amp). This is sufficient to: charge batteries, operate propane furnace, refrigerators, all interior lighting and computer systems. (Continuous).
- Full 120 / 240 VAC, 50 + 50 amp mode operating all equipment on either shore power (connected to the grid) or the Advanced Dynamo generator built in to the vehicle. (Continuous).

Think: “Little cord = little power, Big cord = Big power”.

- The battery charging cord **is not** sufficient to operate: air conditioning, electrical heat, dental support equipment (air compressor, vacuum, sterilizers, etc.) If these support items need to be serviced / operated: plug in shore power or follow generator start-up procedures.

ADI Mobile Health - FACTORY

19425 SW 89th Avenue
Tualatin, OR 97062 USA
www.adi-mobilehealth.com

Phone: +1-503-885-0886
Fax: +1-503-885-0417
tech@adi-mobilehealth.com
sales@adi-mobilehealth.com